


TN-2450 Reset Instruction



wrong position: tooth shape part is not align with the dented line

gear position not correct



rotate the white gear as the direction of the red arrow until the tooth shape part align with the dented line as in the picture below



correct position

push the white gear to the right position as in the picture

